



CODE OF PRACTICE ARSINE

AIGA 050/08

(JIMGA-T-S/36/08/E)

Globally Harmonized Document

Asia Industrial Gases Association

3 HarbourFront Place, #09-04 HarbourFront Tower 2, Singapore 099254
Tel: +65 6276 0160 · Fax: +65 6274 9379
Internet: <http://www.asiaiga.org>



CODE OF PRACTICE

ARSINE

Prepared by the members of the Joint Working Group of AIGA and JIMGA

A. Chuang	Air Products and Chemicals, Inc.
S. Hasaka	Taiyo Nippon Sanso
K. Ikoma	Taiyo Nippon Sanso
H.P. Lei	The Linde Group
I. Lin	Praxair
M. Ang	Air Liquide
K. Maruko	Air Liquide Group / Japan Air Gases
H. Masuda	JIMGA
I. Nakayama	Taiyo Nippon Sanso
E. Ngai	Air Products and Chemicals, Inc.
J. Sameth	Matheson Tri-Gas
R. Tada	Takachiho Chemical Industrial

Disclaimer

All technical publications of AIGA or under AIGA's name, including Codes of practice, Safety procedures and any other technical information contained in such publications were obtained from sources believed to be reliable and are based on technical information and experience currently available from members of AIGA and others at the date of their issuance.

While AIGA recommends reference to or use of their publications by their members, such reference to or use AIGA's publications by their members or third parties are purely voluntary and not binding.

Therefore, AIGA or their members make no guarantee of the results and assume no liability or responsibility in connection with the reference to or use of information or suggestions contained in AIGA's publications.

AIGA has no control whatsoever as regards, performance or non performance, misinterpretation, proper or improper use of any information or suggestions contained in AIGA's publications by any person or entity (including AIGA members) and AIGA expressly disclaim any liability in connection thereto.

AIGA's publications are subject to periodic review and users are cautioned to obtain the latest edition.

Acknowledgement

This Code of Practice for Arsine was developed jointly with the Japan Industrial and Medical Gases Association (JIMGA). It is published in JIMGA as document JIMGA-T-S/36/08/E.

Table of Contents

1. Introduction	1
2. Scope and Purpose.....	1
2.1 Scope	1
2.2 Purpose	1
3. Definitions	1
4. Gas Properties	4
4.1 General.....	4
4.2 Physical properties	6
4.3 Chemical properties.....	7
4.4 Health properties	7
4.5 Flammability properties.....	7
4.6 Environmental properties	7
5. Gas Major Hazards	8
5.1 Fire and explosion hazards	8
5.2 Toxicology	9
5.2.1 Arsine exposure	9
5.2.2 Medical treatment for arsine exposure	10
5.2.3 Leak or release of arsine	11
6. Gas Handling Equipment	11
6.1 Materials of construction	11
6.2 Compatibility of sealing compounds	12
6.3 System pressures and overpressure protection	12
6.4 Valve types & filter types	12
6.5 Tubing.....	13
6.6 Purification materials	13
6.7 System leak tests and purge	13
6.8 System temperature control	13
6.9 Use of electrical control & use of explosion proof equipment	14
6.10 Monitoring system	14
6.10.1 Gas monitoring	14
6.10.2 Flame & smoke monitoring.....	15
6.11 Abatement system	15
6.12 System vent	15
6.13 Regulators	15
7. Process and Operation	15
7.1 Life safety control (gas detection and alarm systems)	15
7.1.1 Monitoring	15
7.1.2 Life safety system.....	15
7.1.3 Management.....	16
7.2 Operational procedures and personnel.....	16
7.3 Ventilation	17
7.3.1 Necessity of ventilation for arsine.....	17
7.3.2 Types of ventilations	17
7.3.3 Consideration for ventilation design	17
7.4 On-going maintenance and Preventive Maintenance (PM) programs.....	18

8. Gas Cylinder Filling/Packaging	18
8.1 Filling facility consideration	18
8.2 Containers	18
8.2.1 Cylinders	18
8.2.2 Valves and pressure relief devices	18
8.2.3 Fill density	19
8.3 Filling equipment	19
8.3.1 Manifolds	19
8.3.2 Compressors	19
8.3.3 Vacuum pumps	19
8.3.4 Pressure gauges	20
9. Storage and Handling	20
9.1 General guidelines	20
9.2 Storage	20
9.2.1 Segregation	20
9.2.2 Storage condition	20
9.3 Handling	21
9.3.1 Essentials	21
9.3.2 Precautions	21
9.3.3 Checking	21
9.3.4 Prohibition and restriction	21
9.4 Security	22
10. Gas Supply to Point-of-use	22
10.1 Process line control	22
10.2 Regulators	22
11. Gas Abatement Systems	22
11.1 Basic principles of abatement	23
11.1.1 Reclamation or recovery	23
11.1.2 Oxidation via incineration	23
11.1.3 Oxidation via wet scrubber	23
11.1.4 Absorption/adsorption and reaction on a treated solid (with metallic oxides)	24
11.1.5 Physical adsorption on solid media	24
11.2 User requirements	25
11.3 Waste stream disposal	25
11.4 Waste Management	25
12. Emergency Response	26
12.1 Preparation	26
12.1.1 Recognition	26
12.1.2 Evaluation	26
12.1.3 Control	26
12.1.4 Information	26
12.1.5 Safety	27
12.2 Response	27
References	28
Conversion Factors	30

1. Introduction

As a part of a programme of harmonization of industry standards, a working group has been set up under joint lead of AIGA and JIMGA.

Arsine is a toxic, colourless gas with a garlic-like odour at room temperature and atmospheric pressure. It is shipped as a liquefied compressed gas under its own vapour pressure of 1.515 MPa. It is also supplied in a gaseous state, diluted with other gases under pressure. It is flammable and highly toxic.

The use of arsine has constantly been growing and this usage is expected to continue to escalate throughout the world. The issue of the safe handling of arsine is a very important and relevant topic to the compressed gas industry as well as the user community of this electronic specialty gas.

Arsine is used as a doping agent for silicon-based solid-state electronic devices. It is thermally diffused into the silicon layer using furnaces or by an ion implantation system (n-type dopant). It is also used to manufacture compound semiconductors such as light-emitting diodes by reaction with a metal organic, such as tri-methyl gallium forming a gallium arsenide layer. Arsine can be inadvertently generated in mining and manufacturing processes involving arsenic compounds and paints and herbicides containing arsenic compounds.

Arsine can be safely handled if equipment is properly designed, maintained and employees are properly trained. As a minimum, all personnel should have access to the arsine Material Safety Data Sheet (MSDS) and training in the use of the MSDS and other reference material.

Note: In this document, arsine is understood to be in the gaseous phase unless otherwise stated.

2. Scope and Purpose

2.1 Scope

This document is intended for the suppliers, distributors and users of arsine and its handling equipment. The document includes guidance for design of equipment, cylinders and valve usage, handling controls and safety. Guidelines on the operational steps associated with the use of arsine and arsine mixtures as well as fire protection, gas detection, ventilation and related safeguards are also included. The manufacture, purification and analysis of arsine are beyond the scope of this documentation, although the general guidance given is also relevant to these processes.

2.2 Purpose

In view of the high toxicity and flammability of arsine where the consequences of improperly handling of arsine, could cause injury, death, and/or facility damage, this publication has been written. This document will provide a good understanding of the potential hazards involved in handling arsine and the guidelines to be taken to minimize risk potential.

3. Definitions [1]

Absolute Pressure: is based on a zero reference point, the perfect vacuum. Measured from this reference, the standard atmospheric pressure at sea level is 1.013 bars (101.325 kPa), abs; however, local atmospheric pressure may deviate from this standard value because of weather conditions and the distance above or below sea level.

Apparatus: Accessory equipment, such as valves, pressure relief devices, regulators, non-return valve (check valve) used with compressed gas.

ADR/RID: European Agreement Concerning the International Carriage of Dangerous Goods by Road (ADR) and Rail (RID).

Compressed Gas: The definition of a "compressed gas" is not uniformly accepted by all countries and

jurisdictions. The definition of United Nation (UN) widely referred is shown below.

(1) UN: A substance or mixture of substances that (1) is a gas at 20 °C (68 °F) or less at an absolute pressure of 0.101 MPa (101.325 kPa, abs) or (14.696 psia) and (2) has a boiling point of 20 °C (68 °F) or less at an absolute pressure of 0.101MPa (101.325 kPa, abs) or (14.696 psia) and that is liquefied, non-liquefied, or in solution, except those gases that have no other health or physical hazard properties are not considered to be compressed gases until the pressure in the packaging exceed an absolute pressure of 0.280 MPa (280 kPa, abs) or (40.6 psia) at 20 °C (68 °F).

For the reference, the definition of Globally Harmonized Systems (GHS) is also shown as follows.

(2) GHS: Compressed gas means a gas which when packaged under pressure is entirely gaseous at -50 °C; including all gases with a critical temperature \leq -50 °C.

Containers: Vessels of various shapes, sizes, and materials of constructions such as cylinders, portable tanks, or stationary tanks, and of designs meeting the specifications of either the American Society of Mechanical Engineers (ASME), Transport Canada (TC), the United States Department of Transportation (DOT), European Agreement Concerning the International Carriage of Dangerous Goods by Road (ADR), Japanese Industrial Standard (JIS), or national authorities, and are filled with compressed gases.

Critical Temperature: The critical temperature is the temperature above which the compressed gas cannot exist in the liquid state.

Cylinder: For the purpose of this document, a cylinder is defined as a transportable container having a water capacity that does not exceed 150 litres, that can be filled with a gas under pressure.

Note: For pure phosphine or phosphine mixtures that are classified as highly toxic, some countries prohibit the use of cylinders larger than 57 litres.

Filling Ratio: This is the ratio of the mass of liquefied gas introduced in a container to the mass of water at 15 °C that would fill the same container fitted ready for use. Also known as fill density, filling factor, maximum fill degree, or maximum fill pressure.

Note: (1) For safety reason, filling ratio may be applied to some non-liquefiable gases such as auto-decomposition, e.g. nitrogen trifluoride.

(2) The water capacity stamped on the cylinder may apply to the minimum water capacity designed without internal fittings, in which case, the net water capacity must be ascertained.

Flammable Gas: For the purpose of this document, a gas is considered flammable when either a mixture of 13 % or less (by volume) with air is ignitable at 0.101 MPa, abs or has a flammable range with air of at least 12% regardless of the lower limit. These limits shall be determined at 0.101 MPa, abs pressure and at a temperature of 20 °C.

Gas Supplier: A business that produces, fills, and/or distributes compressed gases and compressed gas containers.

Handling: Moving, connecting or disconnecting a gas container under normal conditions.

Hazard: Any condition that could potentially cause injury to personnel or property.

Highly Toxic: Gases that have an LC₅₀ in air less than or equal to 200 ppm for a one-hour exposure. See LC₅₀ definition below. National regulations may have additional classifications.

Note: In this document, ppm (parts per million) means ppmv.

HOT Zone: The Hot Zone includes the area immediately around the chemical spill and the surrounding region that may be in serious danger from physical hazards, such as fire or explosion, or chemical exposure. Generally, only fire fighters and emergency response team who are members of a specialized hazmat team will enter the Hot Zone.

Inert Gas: A gas which is not toxic, which doesn't support human breathing and which reacts scarcely or not at all with other substances.

LC₅₀: The median lethal concentration of gas, when administered by continuous inhalation for an hour to 10 albino rats weighing between 200 and 300 grams each, causes death to 50 % of the population within 14 days.

LFL (Lower Flammable Limit or Lower Flammability Limit): The minimum concentration in air of a gas which would burn when ignited. Also referred to as Lower Explosive Limit, LEL.

Material Safety Data Sheet (MSDS): Written or printed information concerning a hazardous material (properties, precautions, etc.) following national regulations. Also referred to as **Safety Data Sheet (SDS)**.

National Standards, Guidelines, Regulations: These are the technical standards set by the regulatory authorities of the country in which the equipment/facility is used, with respect to their design, construction, testing and use. Where available and applicable, these standards shall be followed.

Oxidizer: A substance that in the presence of a fuel, supports and may vigorously accelerate combustion. For example, gaseous oxygen, nitrous oxide or fluorine.

Pressure: The force per unit of area exerted by a gas to its surroundings. The term megapascal (MPa), will be the standard term for pressures used in this document. 1 MPa = 1000 kPa = 20,885.4 psf = 145 psig = 10 bar.

Pressure Relief Device: A pressure and/or temperature activated device used to prevent the pressure from rising above a predetermined maximum and thereby prevents rupture of a normally charged container when subject to a standard fire test.

Shall: The use of the word “shall” in this document implies a strong concern for mandatory instruction.

Should: The use of the word “should” in this document indicates a recommendation.

Tare Weight: The tare weight is the mass of the container and other fittings not removed during the container’s fill or use. It would include the valve, dip tube and any permanently or semi-permanently fixed valve protection device.

Test Pressure: The test pressure of a container is the pressure at which the container is hydraulically or pneumatically tested and is the pressure which shall not be exceeded under any foreseeable normal operating conditions (e.g. during filling).

Toxic Gas: A compressed gas that has a LC₅₀ in air of less than or equal to 5,000 parts per million (ppm) but greater than 200 ppm, for a one-hour exposure. National regulations may have additional classifications.

Threshold Limit Value – Time Weighted Average (TLV-TWA): The concentration to which a person may be exposed, 8 hours a day, 40 hours a week, without harm. (This is the definition from ACGIH -American Conference of Governmental Industrial Hygienist).

UFL (Upper Flammable Limit or Upper Flammability Limit): The maximum concentration in air of a gas, which would burn when ignited. Also referred to as Upper Explosive Limit, UEL.

Valve Outlet Caps and Plugs: Removable attachments that usually form a gas-tight seal on valve outlets provided by the gas supplier with certain gases. (Some caps are designed only for valve thread protection and are not gas-tight.)

Valve Protection Cap: A rigid removable cover provided for container valve protection during handling, transportation, and storage.

Valve Protection Device: A device attached to the neck ring or body of the cylinder for the purpose of

protecting the cylinder valve from being struck or damaged by impact resulting from a fall or an object striking the cylinder.

4. Gas Properties


4.1 General

Arsine is a metal hydride gas with the chemical formula AsH_3 . It is highly toxic with an established LC_{50} that is less than 200 ppm. In addition to its toxicity, it is also flammable and is capable of forming flammable mixtures when mixed with air. It is not considered to be corrosive. It possesses a garlic like odour. [2][3][4]



Arsine is routinely shipped in seamless steel or aluminium alloy cylinders. For reason of safety, cylinders used for arsine will have a test pressure of 4.2 MPa. Some national bodies mandate higher test pressures. The vapour pressure of arsine at 21.1 °C is approximately 1.515 MPa. [2]

The table 4.1.1 shows the property of arsine.

Table 4.1.1 Property of Arsine

Properties	SI	English	Reference
Synonymes	arsenic tri-hydride, hydrogen arsenide, arsenic hydride, arsenous hydride		
Molecular Formula	AsH ₃		
CAS Number	7784-42-1		
UN Number	UN2188		
Physical State	Gas		
Colour	Colourless		[2][3][4]
Odour	Garlic odour		[2][3][4]
Molecular Weight	77.945		
Boiling Point	-62.48 °C	-80.46 °F	[5]
Freezing Point	-116.87 °C	-178.37 °F	[5]
Decomposition Temperature Range	230 to 300 °C	446 to 572 °F	[2][4][5][6]
Critical Temperature	99.85 °C	211.73 °F	[2][5]
Critical Pressure	6.41 MPa	930.13 psia	[2][5]
Critical Volume	132.5 cm ³ /mol	8.086 in ³ /mol	[5]
Critical Density	0.5883 g/cm ³	36.73 lb/ft ³	[5]
Critical Compressibility Factor	0.274		[5]
Density of Liquid @ 21.1 °C at 1.515 MPa	1.335 g/cm ³	83.55 lb/ft ³	[2]
Density of Gas @ 21.1 °C at 1.515 MPa	3.228 kg/m ³	0.202 lb/ft ³	[5]
Relative Density of Gas @ 21.1 °C at 101325 Pa (air=1)	2.691		[2]
Vapour Pressure @ 21.1 °C	1.515 MPa	219.7 psia	[2]
Solubility In Water @ 25 °C at 101325 Pa	676.12 ppm (wt)		[5]
pH	Not applicable		
Volatility	Not applicable		
Odour Threshold (varies with impurities)	0.5 ppm		[4][7]
Evaporation Rate	Not applicable		
Flash Point	Not applicable		
Lower Flammable Limit	5.1 %		[6][8]
Upper Flammable Limit	78 %		[6][8][9]
Autoignition temperature	285 °C	545 °F	[10] [11]
Molecular Shape	trigonal pyramidal		
Dipole Moment	0.20 D		[5]
Standard Enthalpy of Formation @ 25 °C, Δ _f H ^o _{gas}	+66.44 kJ/mol		[5]
Structure			

The figure 4.1.2 and the figure 4.1.3 describe the arsine vapour pressure versus temperature using its unit of centigrade degree C and Fahrenheit, respectively.



4.2 Physical properties

Decomposition of arsine is possible in the presence of light.

Arsine is decomposed by the effect of ultraviolet rays, and it decomposes more rapidly as the ultraviolet ray intensity increases. [12]

Although arsine has positive heat of formation (+66.44 kJ/mol), stability tests that were conducted showed that even with input of 100 J decomposition did not take place in the cylinder. [13]

It is best to avoid sources of ignition, sparks, and flames because of the flammable properties of arsine. LFL of arsine is 5.1 % and UFL is 78 %. [8][9] Because of these flammable properties, the concern for explosions must be recognized. Arsine poses a severe fire hazard and a moderate explosion risk.

A flammable arsine mixture in air requires an ignition source to ignite because it is not pyrophoric. The autoignition temperature of arsine is 285 °C. [10][11]

Arsine is stable at room temperature and begins to decompose at about 230 °C (446 °F) with complete decomposition at about 300 °C (572 °F). [2][4][5][6][9]

4.3 Chemical properties

Arsine is incompatible with oxidizing materials, members of the halogen family, acids, and other combustible materials. Arsine is a strong reducing agent and reacts vigorously with oxidizers such as potassium permanganate, sodium hypochlorite, oxygen, ozone, chlorine, fluorine, and nitric oxide. Arsine will have some reaction with the alkali metal family.

Arsine is not known to polymerize.

4.4 Health properties

Refer to section "5.2 Toxicology".

4.5 Flammability properties

Refer to section "5.1 Fire and explosion hazards".

4.6 Environmental properties

With proper control, arsine can be controlled and pose no significant threat to human life and the environment. But when arsine enters the environment through an accidental release, it can contaminate the land, the water and the air with potentially disastrous results. Many countries have strict regulations and measures to be taken should a release occur. The users of arsine should review the regulations that apply.

- Arsenic compounds including arsine are considered Hazardous Air Pollutants in certain jurisdictions. These pollutants are known or suspected to cause cancer or other serious health effects, such as reproductive effects or birth defects, or adverse environmental effects. [14]
- Arsine users should employ a variety of tools to prevent direct pollutant discharges into waterways, municipal wastewater treatment facilities, or allow polluted runoff.
- Emergency response programs are established and at times mandated to eliminate any danger to the public and the environment posed by hazardous substance releases. To help fulfil this mission, local governments may require that the person or organization responsible for an arsine use notify the government when the amount onsite reaches a pre-determined limit.
- If a release or spill of arsine occurs, the government may require additional notifications be made. These requirements vary by governments.
- Guidance documents should be obtained from the local government agency to offer direction in following regulations and control emissions. Legal action may be undertaken to pursue those who do not fully comply with the requirements of environmental legislation.
- Risks to human health and the environment will vary considerably depending upon the type and extent of exposure. Arsine users are strongly encouraged to characterize risk on the basis of locally measured or predicted exposure scenarios.

Risk assessment values or other media quality standards may be used in countries to evaluate the health risks posed by exposures to toxic chemicals. These values are typically specified as concentration limits that must not be exceeded to avoid health risk. These published values can be compared directly to information about the concentration of a chemical in the environment to identify potential health hazards. If a chemical concentration exceeds a relevant media quality standard, action to reduce environmental contamination or exposure is warranted.

The table 4.6 shows the United States published data of arsenic.

Table 4.6 The United States published data of arsenic

Chemical: ARSENIC		7440-38-2	
CAS Number:		7440-38-2	
Risk Assessment Values or Standards	Value	Units	Reference
Inhalation cancer risk value (potency)	0.0043	ug/m ³	[15]
Inhalation non cancer risk value (reference concentration)	Data gap		-
National ambient air quality standard	Gap in regulatory coverage		-
Comprehensive Environmental Response, Compensation, and Liability Act (CERCLA) reporting limit.	0.45	kg	-
Ingestion cancer risk value (potency)	1.5	mg/kg-day	[15]
Ingestion non cancer risk value (reference dose)	0.0003	mg/kg-day	[15]
National water quality standard	0.01	mg/L	[16]

5. Gas Major Hazards

5.1 Fire and explosion hazards [17][18][19][20][21]

Arsine is flammable. The flames from burning arsine may be several meters long and may shift quickly with the slightest breeze. By-products of arsine combustion are toxic arsenic oxides (solids). These arsenic oxides can be absorbed by the skin. Therefore, personnel must wear protective clothing and self-contained breathing apparatus in fighting arsine fires. Only trained personnel should respond to arsine fires. As in the case of a fire of any flammable gas, the flow should be stopped if it is safe and practical to do that. Normally this can be accomplished by shutting off the cylinder valve.

In order for an arsine ignition to occur, three conditions need to occur simultaneously:

- (1) The concentration of arsine must be within its flammable limits
- (2) The presence of sufficient air or an alternate oxidizing source
- (3) A source of ignition must exist.

Flammable gases shall not be used near open flames, source of heat, adjacent to oxidizers or non-explosion proof electrical systems. Transportation, storage and use of arsine should be in well ventilated areas.

Arsine has a flammable range nearly equivalent to that of hydrogen.

Arsine may begin to slowly decompose into its elements of arsenic and hydrogen at temperatures of 230 °C to 240 °C. [2][4][5][6] A temperature of 300 °C is recognized as the temperature where decomposition is fully accelerated. [2][4][5][9]

If the flow of arsine cannot be stopped, let it burn until the fire stops naturally, keeping adjacent cylinders and equipment cool. If an arsine fire is extinguished and the flow of arsine is not stopped, a hazardous combustible mixture may continue to form. It is possible that the mixture can be ignited, explode, cause more damage and restart the fire. Appropriate measures must be taken to protect persons from cylinder rupture in the case of cylinder failure or piping failure.

Although an arsine fire shall not be extinguished until the flow of arsine can be stopped, water sprays, etc, should be used to extinguish any secondary fire and to prevent the spread of fires. The arsine containing equipment may be kept cool by water sprays to decrease the rate of arsine release or to prevent further damage. This is best done at a distance. Water used in fire fighting could become contaminated. There should be measures in place to contain and possibly treat such contaminated water.

Remote-controlled water spray equipment is preferable to use of hoses in cooling equipment and to reduce the spread of fire. Should the use of hoses become necessary, operating personnel should remain behind protective structures and upwind of the fire.

Fire-fighting or other emergency personnel should communicate and cooperate with personnel who are familiar with the physical and toxic properties of arsine. They also should communicate and cooperate with personnel who are familiar with materials in the area of the emergency. Unexpected conditions may require special actions.

If a cylinder of arsine or supply piping system is ruptured in such a manner that quantities of arsine are released and ignited, hazardous conditions will exist.

- **Flame effects:** The major concern is that the generated flames will impinge on surrounding valves and piping thus weakening these structures with the possibility of failure taking place. Hot balls or jet fires may be present. Wind velocity and direction may change the shape of the fire ball or jet to an elliptical shape and push it further downwind of the release.
- **Radiation effect:** The major concern is that radiation effects from the fire can result in the excessive heating of adjacent equipment and process lines.
- **Reaction by-products:** Oxides of arsenic (e.g. arsenic trioxide and arsenic pentoxide) will form as a result of the fire and deposit as a dust over the affected facility and be carried downwind of the fire. Such oxidized arsenic is toxic by inhalation, ingestion and absorption.

A thorough Process Hazard Analysis with identified sufficient safeguards must be in place to minimize the risk of a potential incident if the operating personnel should err in procedures or equipment fails.

5.2 Toxicology

5.2.1 Arsine exposure

Arsine has a garlic like odour with an odour threshold of about 0.5 ppm. [4][7] Cases of arsine intoxication have been recorded without the subject being aware of exposure.

Literatures have been reporting the symptoms of arsine poisoning by exposure for a long time, but its acute toxicities to humans are not known well. In this document, some reports are shown for the reference as follows.

Wald and Becker reported that exposures to 250 ppm of arsine are instantly lethal; exposure to 25-50 ppm is lethal after 30 minutes and 10 ppm is lethal after longer exposures. [7]

Henderson and Haggard reported that fatal after exposures of 30 minutes is 250 ppm; dangerous after exposure of 30 minutes to 1 hour is 16 to 60 ppm; slight symptoms after exposure of several hours is 3 to 10 ppm. [22]

ACGIH shows that exposure to 9.72-32.4 mg/m³ (3-10 ppm) may induce symptoms within a few hours, the concentration of 32.4-194.4 mg/m³ (10-60 ppm) may exert a hazardous effect within 30 to 60 minutes, and of 810 mg/m³ (250 ppm) is immediately fatal. [23]

Note: Arsine exposure is only inhalation and is not absorbed by the skin. Arsenic oxide after burning arsine will be absorbed by the skin.

The major hazard associated with exposure to arsine is massive haemolysis and associated acute renal failure. Symptoms may be delayed up to two days and may include: [24][25][26]

- Headache
- Dizziness

- Garlic odour of breath
- Numbness, coldness, tingling of hands and feet
- Nausea
- Vomiting, Abdominal cramping
- Abdominal tenderness and rigidity
- Bronzing of the skin
- Pulmonary edema
- Jaundice and hepatomegaly
- Anaemia and leukocytosis
- Shock
- Delirium and coma

The major effect noted as a result of low level chronic exposure is haemolytic anaemia. Other side effects from constant exposure include but are not limited to; headaches, nausea, vomiting, shortness of breath on exertion, garlic like odour of the breath, and puffiness of the jaws and eyelids. The table 5.2.1.1 shows the toxic information of arsine.

Table 5.2.1.1 The toxic information of arsine

Chemical: ARSINE			
CAS Number:	7784-42-1		
Conversion Factor: 1 ppm = 3.19 mg/m ³ [6]			
	Value	Units	Reference
LC ₅₀ /mice 1 hour	20	ppm	[27]
LC ₅₀ /rat 1 hour	178	ppm	[28]
PEL TWA (Permissible Exposure Limit) Personnel Inhalation Exposure	0.050	ppm	[6]
	0.2	mg/m ³	[25]
TLV-TWA (Threshold Limit Value - Time Weighted Average) Personnel Inhalation Exposure	0.005	ppm	[29]
Recommended Exposure Limit Ceiling 15 minute(s)	0.002	mg/m ³	[6][25]
NIOSH Immediate Danger to Life and Health Concentration (IDLH)	3	ppm	[6][25]
AEGL (Acute Exposure Guideline Levels)			[30]
	AEGL-1 (30 min)	NA	ppm
	AEGL-2 (30 min)	0.24	ppm
	AEGL-3 (30 min)	0.7	ppm
NA: Not appropriate			
Notes:			
1. The OSHA limits are the legal exposure limits allowed by the United States law and are enforceable.			
2. The ACGIH limits are suggested values and are not enforceable by law. In 2007 ACGIH changed the TLV-TWA from 0.050 ppm to 0.005 ppm. The CGA opposed the change and submitted reports showing that the body of data referenced did not provide sufficient scientific evidence to support a reduction of arsine TLV.			

Note: Combustion products resulting from the exposure of arsine to a flame are toxic.

Within the body, arsine is oxidized to other arsenic species. Arsenic and arsenic compounds are recognized by many countries as carcinogenic to humans and induce genotoxic effects in experimental systems and in humans.

Measurement of arsenic levels (above 0.2 mg/L) in the urine is an appropriate diagnostic test for exposure.

5.2.2 Medical treatment for arsine exposure

Detailed pre-hospital and hospital management practices for treatment of arsine exposures can be found in the "Medical Management Guidelines for Acute Chemical Exposures" [4].

Key points from these guidelines for arsine:

Primary route of entry is inhalation. It is a highly toxic systemic poison. The primary effect is massive destruction of red blood cells resulting in acute kidney failure. The odour of arsine is not always detected during serious exposures; since symptoms may be delayed, ALL exposure victims should be evaluated at a medical facility. Symptoms of acute exposure can be delayed up to 2-48 hours depending on exposure intensity

Victims exposed only to arsine gas do not pose serious risks of secondary contamination to personnel outside the Hot Zone and do not need decontamination. Although small amounts of arsine can be trapped in the victim's clothing or hair after an overwhelming exposure, these quantities are not likely to create a hazard for response personnel outside the Hot Zone.

There is no antidote for arsine poisoning. Treatment is symptomatic and consists of measures to support respiratory, vascular, and renal function. If haemolysis develops, urinary alkalinisation is initiated.

5.2.3 Leak or release of arsine

In view of the toxic nature of arsine, in the case of a leak all personnel should be immediately evacuated from the affected areas. Only trained emergency response personnel should enter the area, properly equipped with self-contained breathing apparatus. [17]

In the event of the release of a cylinder of arsine, personnel in the immediate area of the release will likely be at risk. As in the case of the release of any toxic gas, first responders should station themselves upwind of the release point.

Because of the high toxicity of the material, any release of the product, whether accidental or intentional, will likely require the filing of a report with the governing agency for environmental protection.

6. Gas Handling Equipment – general considerations

The equipment used to handle arsine must be designed, constructed and tested in accordance with the regulatory requirements of the country in which the equipment is operated. The equipment must be designed to withstand the maximum pressure and temperature at which it is to be operated. A Process Hazard Analysis (PHA) shall be performed and documented on all arsine systems. As arsine is a highly toxic and flammable gas, consideration should be given to the following issues when designing systems to handle arsine:

- (1) Materials of construction
- (2) Compatibility of sealing compounds
- (3) System pressures and overpressure protection
- (4) Valve types & filter types
- (5) Tubing
- (6) Purification materials
- (7) System leak tests and purge
- (8) System temperature control
- (9) Use of electrical control and use of explosion proof equipment
- (10) Monitoring system
- (11) Abatement system
- (12) System vent
- (13) Regulators

6.1 Materials of construction

Selection of metals and non-metals shall be made taking into account the compatibility guide listed below. It is extremely important that all gas control equipment be compatible with the gas being passed through it. The use of a device that is not compatible with the service gas may damage the unit and

cause a leak that could result in property damage or personal injury. If a material is not listed and is required to be used in arsine service and is thought to be compatible it should be first tested to confirm suitability prior to use under defined temperature, pressure and flow conditions.

The table 6.1.1 material compatible guide is prepared for use with dry arsine at normal operating temperature of 21.1 °C; information may vary if different operating conditions exist.

Table 6.1.1 Material compatibility guide [31]

		S= Satisfactory									U = Unsatisfactory					? = Unknown or limited data				
		MATERIALS OF CONSTRUCTION																		
ARSINE	METALS									PLASTICS						ELASTOMERS				
	Steel	303 SS	304 SS	316 SS	Monel®	Aluminium	Brass	Copper	Zinc	Kynar®	PCTFE	Polycarbonate	PVC	Teflon®	Tefzel®	Buna-N	Kelrez®	Neoprene®	polyurethane	Viton®
	S	S	S	S	S	S	S	S	?	S	S	?	S	S	S	S	S	S	U	S

Note: (1) Nickel can cause decomposition of arsine.

(2) Some plastics and elastomers if used, absorb arsine.

(3) While ISO 11114-1 addresses concerns for hydrogen embrittlement, and while it is also acknowledged that P-200 requires an “H” stamp for steel cylinders charged with arsine, there is no conclusive proof that arsine is an embrittling gas.

6.2 Compatibility of sealing compounds

Consideration should be given to the compatibility of lubricants, seals, greases and sealing compounds which under normal or upset conditions come in contact with arsine. Refer to vendor supplied data.

6.3 System pressures and overpressure protection

System pressures are low due to the low vapour pressure of arsine at 21.1 °C, which is 1.515 MPa. Proper design should address conditions where system pressure may be subjected to sub-atmospheric conditions and draw in air or other gas stream contamination that is utilized in the system. Due to the hazardous nature of arsine, a conservative engineering and design approach shall be applied to the system design as applicable whether for pure arsine or arsine mixtures.

Gaseous mixtures of arsine are routinely packaged at pressures at or below the rated cylinder working pressure. Gas panels typically use a gas regulator to reduce the cylinder pressure to the operating condition.

Special care is needed to ensure that all components in the system are rated for these pressures.

Where system design pressures can be exceeded due to any component failure or operator error, proper overpressure protection shall be provided. Overpressure protection may involve safety relief devices and/or instrumented systems depending on local code requirements.

Piping system safety relief valve outlet must link to appropriately designed abatement system (see chapter “11. Gas Abatement Systems”).

6.4 Valve types & filter types

Metal diaphragm valves and bellows valves provide a better leak tightness as compared to packed valves. The use of non-metal material for diaphragms or bellows is not recommended due to permeation potential of arsine thru the non-metal. Ball valves, butterfly valves, gate valves, needle

valves, or packed valves are not recommended for use in arsine service due to a higher leak potential either through or around the valve seat or the valve body.

Mesh filters made of stainless steel work well as do those of Teflon[®]. Sintered metal filters are also recommended.

The use of restrictive flow orifices (RFO's) has been a routine practice since the mid 1980's. The restrictor has a small diameter of, for example, 0.152 mm (0.006 inch), 0.254 mm (0.010 inch) and 0.3 mm, and is of stainless steel materials of construction. While early designs had a filter element capable of capturing particles that were greater than two microns, the use of such filters are not currently part of RFO's in service today. The RFO threads into the valve outlet. In the event of a shearing of a process line or a valve being accidentally opened, the RFO significantly reduces the amount of gas that would be released and that would need to be environmentally treated. Some jurisdictions and insurance companies require the use of the RFO.

Also during the 1980's, air actuated valves began to be used. It allowed for remote opening and closing of the cylinder valve, and afforded an extra measure of safety both at the filling as well as at the point of use.

6.5 Tubing

Some national bodies or insurance companies require the use of coaxial tubing when the tubing is outside of an exhausted enclosure. Welded or metal face seal connections are the preferred connection methods due to their leak integrity.

6.6 Purification materials

Arsine is offered at high purity by the supplier. Purities offered range from low 99.995 % to 99.9999+ %. Purification materials can be as basic as molecular sieves to remove water and other impurities and more sophisticated materials may be used to also remove moisture and specific impurities such as sulphur, germanium, etc.

Proper system purge must be done prior to the use of the purifier or removal.

6.7 System leak tests and purge

After system installation or maintenance, they must be leak checked and purged prior to commissioning.

Connections which are routinely re-made in the process (e.g. cylinder pigtail connections) should be leak checked at a pressure higher than maximum usage pressure prior to system purging.

The best purge systems are those that are automated. The number of purge cycles is a function of the inert purge gas pressure available, the use of vacuum generators, the size of the tubing/piping system to be purged and the desired final dilution value. Common purge gases are nitrogen and helium. Hydrogen is also used as a purge gas. Typical gas delivery systems shall be purged to a safe level of arsine. The use of manual purge control has a higher potential for operator error and requires clear operator instructions if utilized.

6.8 System temperature control

Systems operate at varying temperatures depending on how the arsine is being used. Proper design should address conditions where system temperature may vary from room temperature. When working with compressed liquids, refer to the vapour pressure versus temperature relationship shown earlier in this document.

Some systems may require external heating system of the cylinder to maintain system flow. In such cases, careful engineering review must be taken to ensure the temperature never exceeds 65 °C and

creates potential liquid full condition.

Some systems may also require heating to maintain constant temperature and/or prevent condensation of arsine during use. The preferable method is use of a temperature-controlled environment. Direct heating using of electrical resistance heater on a cylinder has caused accidents and is least preferred method.

Note: Arsine starts to decompose at the temperature of 230 °C. [2][4][5][6]

6.9 Use of electrical control & use of explosion proof equipment

Since arsine is flammable, electrical systems must meet the requirements of the local regulations covering flammable classifications.

These classifications are for generic volatile flammable liquids or flammable gases that if mixed with air may burn or explode. In such cases the liquids, vapours, or gases will normally be confined within closed containers or closed systems from which they can escape only in case of accidental rupture or breakdown. It should be noted that ignitable concentrations of gases or vapours of flammable gas, flammable liquid–produced vapour, or combustible liquid–produced vapour mixed with air are normally prevented by having forced mechanical ventilation, which is under negative pressure. This could become hazardous through the failure or abnormal operation of the ventilating equipment.

6.10 Monitoring system

6.10.1 Gas monitoring

There is a need to ensure that each individual is protected by arsine detection systems, which are accurate, efficient and easy to use/maintain.

Arsine is a colourless, flammable, and highly toxic gas. It has a garlic-like odour that can be detected at concentrations of 0.5 ppm [4][7] and above. This level of detection does not provide adequate warning of hazardous levels. Because arsine is non irritating and produces no immediate symptoms, persons exposed to hazardous levels may be unaware of its presence. A gas monitoring system continuously monitors primary locations for arsine including but or not limited to the following areas:

- Storage
- Operator areas
- Gas cabinets
- Fume hoods
- Process rooms

The gas monitoring system shall have a backup source of power.
Life safety control is discussed in greater detail in section 7.1.

Detection methods vary, as does their sensitivity to arsine. It is desirable to have a system capable of networking existing systems from various manufactures, and the ability to accommodate ongoing expansion. Typical detector types suitable for arsine are:

- Photo-absorption
- Photo-ionization
- Electrochemical
- Colorimetric tape
- Thermal conductivity
- Catalytic bead

A gas detection system with a sensing interval not exceeding 5 minutes is recommended and may be required in certain jurisdictions.

6.10.2 Flame & smoke monitoring

Since arsine is flammable, monitoring for a flame/smoke may be applicable. However, the greater hazard is the high toxicity of the gas at low ppm levels. This toxicity concern occurs well below the Lower Flammable Limit of arsine. Thus, it is recommended that monitoring should be directed to ppm emissions as opposed to flame monitoring.

Note: Arsine fires have occurred without the gas monitoring system detecting a leak due to fire consuming all the arsine.

6.11 Abatement system

Refer to section "11. Gas Abatement Systems".

6.12 System vent

All vents in system must be directed to abatement system. These include system pressure relief devices, vacuum pump exhaust, system vent and vacuum venturi exhaust.

6.13 Regulators

Refer to section "10.2 Regulators".

7. Process and Operation

7.1 Life safety control (gas detection and alarm systems)

Sound procedures shall be in place to control worker exposure to arsine and its by-products. Compliance to such a program will prevent adverse effects of exposure in the workplace through air exposure or through skin exposure. Specific compliance activity may be prescribed by country regulations. The following items should be considered part of a Life Safety Control program:

7.1.1 Monitoring

- (1) Environmental workplace air/land monitoring:
Occupational exposure shall be controlled so that no worker is exposed to concentrations greater than allowed either as gas or solid inorganic compound.
- (2) Monitor calibration/inspection:
Routine inspection of monitoring equipment to verify performance and reliability.
- (3) Monitor operation/performance of abatement systems:
Routine inspection of abatement equipment to verify performance and reliability.
- (4) Appropriate leak detection devices should be installed to trigger emergency response actions in compliance with national regulations.

7.1.2 Life safety system

- (1) Periodic review of Heating Ventilation and Air Conditioning (HVAC) air balance through building, fume hoods, gas cabinets and abatement systems:
With time, air flows/exhausts may change and required capture velocities may be under required levels. Ventilation dampers should be locked in place to prevent the altering of required ventilation between air balances.
- (2) Alarm testing and inspection:
Routine testing and inspection of alarm systems to verify performance and reliability.
- (3) Since arsine is a flammable gas, fire fighting systems must be considered and should follow national regulations.
- (4) Appropriate gas scrubbing or ventilation systems should be installed to handle gas leaks.
National regulations may require gas scrubbing or ventilation to handle gas leaks.
- (5) Gas storage areas should be designed with more than one exit.

7.1.3 Management

- (1) Proper work clothing management:
Daily change outs, place for contaminated clothing, separate locker room from manufacturing environment.
- (2) Training and re-certification in use of proper Personnel Protective Equipment (PPE) for workers who are required to wear respiratory protection must be medically evaluated and fit tested to confirm worker ability and clearance for use.
- (3) Training and emergency response:
Training should be conducted on the proper emergency response to situations that involve the possible release or exposure to arsine and by-products.
- (4) General awareness training:
Personnel involved in the manufacturing, processing, maintenance, handling, storage and/or transportation shall be trained on the exposure effects (signs, symptoms, medical attention) of arsine and by-products using MSDS and other safety information on the environment and to personnel. Additional training may be required by local jurisdictions which include personnel safety, preventive maintenance and environmental management programs.
- (5) Record keeping programs:
A program should be documented explaining what to record, when to record, how often to record, place of record storage and length for records to be stored before disposal.
- (6) Periodic medical surveillance must be made available for all workers which meet local government requirements. Documented work history, medical history captured. Some governments may require annual chest X-ray, careful examination of skin for the presence of chronic skin lesions, blood work review.
- (7) Proper labelling of products/containers:
With complete name and applicable hazards as required by regulations.
- (8) Clear, documented work practices/procedures:
Control of equipment, process clean-up, waste disposal, and operations control.
- (9) Emergency action plan – response and evacuation protocols for site alarms, releases, and abatement of loss of contaminant.

7.2 Operational procedures and personnel

Clearly defined written work instructions are required to assure safe handling and processing of arsine. The work instruction should describe in sufficient detail the information needed on how to perform a specific task. These work instructions may exist as text, posted instruction, matrix, or a flowchart. Clarity is the key. Latest versions of the work instructions should be readily available to the operator should questions arise.

Operators must be consulted and trained when procedures are changed. All operations involving arsine shall be covered by “clear language” written operating procedures. A risk assessment should be carried out on all operations involving arsine.

Components and materials that may be used on arsine systems shall be clearly identified, carefully stored and handled to ensure that they do not become contaminated. It is recommended that cylinder valve outlet connections gaskets are only handled while wearing approved gloves. This will avoid the risk of:

- Contamination of the gaskets by the natural oils found on the skin
- Contamination of the operator from residue arsine by-products found on the used gasket

All personnel involved in handling of arsine and the operations of arsine systems shall be adequately trained. This training shall include the importance of cleanliness and the need for exclusive use of specified materials and components on arsine systems.

Personnel who operate gas systems shall have a good understanding of the properties, fire & explosion hazards and toxicity of arsine. They should also be trained to take appropriate action in the advent of an emergency. Wherever possible, preventive measures shall be considered to protect

operators (e.g. gas cabinets, fume hoods, Personal Protective Equipment (PPE), remote controlled valves and barrier walls).

7.3 Ventilation

Proper ventilation is required for storage areas, gas cabinets, fume hoods and areas where arsine is processed, stored or handled. Regulations may vary by country and should be verified, but common guidelines are as follows:

7.3.1 Necessity of ventilation for arsine

- (1) Do not vent flammable and toxic gases to the atmosphere except through a properly designed abatement system.
- (2) Mechanical ventilation shall be used to exchange air where arsine is processed or handled to quickly exhaust any fugitive arsine emissions.

7.3.2 Types of ventilations

- (1) Indoor storage and use areas and storage buildings for compressed gases and cryogenic fluids shall be provided with mechanical exhaust ventilation or natural ventilation, where natural ventilation can be shown to be acceptable for the material as stored. In certain jurisdictions, the use of natural ventilation must be approved by governmental and/or local authorities.
- (2) For indoor storage, forced ventilation is required and should follow national regulations.
- (3) Gas rooms shall be provided with an exhaust ventilation system.
- (4) Where outdoor storage is allowed, forced ventilation is generally not required.

7.3.3 Consideration for ventilation design

- (1) The gas cabinet or exhausted enclosure shall be provided with an exhaust ventilation system designed to operate at a negative pressure relative to the surrounding areas.
 1. The velocity at the face of access ports or windows, with the access port or window open, shall be adequate to protect the user from fugitive emissions. In the United Kingdom, a minimum velocity of 1m/s across the face of the small valve manipulation opening is recommended for normal operating conditions.
 2. The number of air exchanges per hour (inside the gas cabinet or exhausted enclosure), may be regulated by local authorities.
- (2) Mechanical ventilation rate shall be adequate. In the United States, the rate of not less than 0.3 cubic meter/minute/square meter (1 cubic foot/minute/square foot) of floor area over the area of storage or use is required.
- (3) The exhaust system shall take into account the density of the potential gases released and leak points.
 1. For gases that are heavier than air, like arsine, exhaust should be taken near the floor.
 2. Some arsine mixtures (helium, hydrogen) are lighter than air, exhaust should be taken near the ceiling.
 3. The location of both the exhaust and inlet air openings shall be designed to provide air movement across all portions of the floor or room to prevent the accumulation of vapours.
- (4) Exhaust ventilation should not be re-circulated within the room or building if the cylinders, containers, or tanks stored are capable of releasing hazardous gases, like arsine.
- (5) Ventilation systems shall discharge at an adequate distance from intakes of air-handling systems, air conditioning equipment, and air compressors.
- (6) Storage and use of compressed gases should be located at an adequate distance from air intakes.
- (7) In the United States where powered ventilation is provided, a manual shutoff switch should be provided outside of the room in a position adjacent to the principal access door to the room or in an approved location. The switch shall be the break-glass or equivalent type and shall be labelled as follows: *VENTILATION SYSTEM EMERGENCY SHUTOFF*.
- (8) Where mechanical ventilation is provided, the system shall be operational as minimum during the time the building or space is occupied.

(9) There shall be an alarm system that will activate in the event of the loss of ventilation.

7.4 On-going maintenance and Preventive Maintenance (PM) programs

It is essential that equipment in which arsine is handled is held to a high standard and to assure that this is maintained in a routine, controlled and safe manner. Particular attention should be provided to any replacement parts for compatibility with arsine and other system products.

Preventive action is directed at eliminating potential causes of equipment failure before they occur. The manufacturer's *Equipment Manual* provides guidelines for preventive maintenance management of their equipment. It is the responsibility of each user to ensure proper control exists. Users of arsine should have a strong *Preventive Maintenance* program installed and implemented, at all sites that process or handle arsine. This program driven by corporate management generally exceeds the equipment manufacturer's recommendations.

8. Gas Cylinder Filling/Packaging

8.1 Filling facility consideration

Good practices for filling facilities should follow those as described under the more general "9.Storage and Handling" below.

8.2 Containers

8.2.1 Cylinders

Arsine is routinely packaged in seamless steel cylinders or aluminium alloy cylinders with a minimum test pressure set by the regulatory body. Low pressure welded cylinders may be accepted for this service, with a special approval that has been granted by the regulatory body.

The cylinder size of arsine and its mixtures are limited by local government regulations. In Japan, maximum cylinder size is 49 L and 57 L in the United States except for mixtures less than 10 vol %.

Cylinders that are used in high purity electronic arsine service, generally have special internal pre-treatment to maintain gas purity. This treatment is provided by the gas supplier.

Containers shall be certified and tested regularly in compliance with national standards. Container re-test shall follow national standards or the container manufacturer's country laws and regulations, whichever is more stringent. Containers failing to meet these standards must be removed from service. If they can be repaired to meet the standards, they can be put back to use; otherwise they shall be scrapped. In some countries, arsine cylinders can not be used in other services.

Prior to fill, care must be exercised to ensure that a container has not been damaged. Pre-fill inspection of containers and correct verification of their pressure rating prior to filling is very important.

8.2.2 Valves and pressure relief devices

It is recommended that diaphragm seal valves be used for arsine in that it provides a level of leak tightness that is not normally achievable with a packed valve. The diaphragm valve can be either a diaphragm packless or a tied diaphragm valve. Some jurisdictions mandate the use of the diaphragm valve, such as the United States and Europe.

There are different types of valve outlets that are used for arsine in Asia, North America, and Europe. It is important that the ancillary equipment used to connect to the cylinder valve be of the same thread configuration as the cylinder valve outlet to insure a leak tight connection. Most countries require a gas tight valve outlet cap on the cylinder valve.

There are a variety of different cylinder valve inlets that are in use today for arsine as well as all gases. There are also a variety of cylinder neck threads that are used worldwide. The threads on the valve inlet must match the threads on the container neck. It is very dangerous to match cylinders and valves that have been manufactured to different national standards since the possibility exists that the valve, under pressure, could be ejected from the cylinder.

The use of pressure relief devices for cylinder valves with arsine is required in Japan and Korea. However, in the United States and Europe, because of the toxicity of arsine pressure relief devices are prohibited. In other countries, pressure relief devices are neither required nor prohibited.

8.2.3 Fill density

The United Nations P-200 Packaging Note currently permits a maximum fill density of 1.1 kg/L for arsine packaged in cylinders with a test pressure of 300 bar (30 MPa).

The maximum fill density for arsine in Japan is 0.416 kg/L.

In the United States the maximum fill density based on liquid full cylinder at 54.4 °C (130 °F) is 1.26 kg/L, however most customers have it filled in the range of 0.50 - 0.60 kg/L due to local regulations or insurance requirements.

The maximum filling ratio for Europe is 1.1 kg/L.

8.3 Filling equipment

Many countries regulate the disposal of arsenic contaminated wastes. Any equipment in contact with arsine may be treated as a hazardous waste when the time comes for disposal. Proper clean-up procedures and employee protection guidelines should be documented and understood.

8.3.1 Manifolds

Manifold components in contact with arsine filling shall be designed with compatible materials listed in this document. When not under arsine pressure, manifolds should be back-filled with an inert gas (e.g. helium, nitrogen, argon) and plugged to ensure that any contaminants are excluded from the manifold system. Filling manifolds should be located in well-ventilated areas. To reduce potential quantity of gas released in an accident and reduce waste, small diameter tubing and lengths are preferred. The filling manifold should be made utilizing welded fitting and metal face seal fitting. The use of threaded fitting should be avoided.

Refer to section 6.7 for "System leak tests and purge" practices.

8.3.2 Compressors

Since arsine is a liquefied gas, compressors are not normally used for pure gas.

8.3.3 Vacuum pumps

Vacuum pumps in contact with arsine are typically either dry pumps or those using a fluorinated fluid (e.g. Fomblin®). There is no hazard to use a hydrocarbon oil pump. However, wet pumps risk oil contamination by arsine and proper waste management is required.

Dry pumps are recommended due to no oil contamination concern. In addition, wet pumps have the potential for oil back-streaming if proper back-streaming barriers are not maintained properly. If back-streaming occurs, arsine (and system manifold) contamination will occur and downtime/clean-up can be lengthy. Personnel must exercise care when performing vacuum pump maintenance, especially for wet pumps where the oil may have absorbed arsine.

8.3.4 Pressure gauges

Pressure gauges are used to monitor the pressure within the arsine system. Analogue and digital pressure gauges may be used as necessary. However, the pressure gauge dead volume should be considered along with ease of inert gas purge. Gauges shall be placed so they are easily monitored by the operator. Since arsine is flammable, the use of digital pressure gauges (operated by electricity) should be at low voltage intrinsically safe (via low voltage or electrical barriers) to avoid ignition source potential.

9. Storage and Handling

Good practices for storage and use of arsine are listed below.

9.1 General guidelines

- (1) All facilities must have an emergency response plan which should include the plan for gas releases and emergency evacuation (more information in AIGA 004/04 and EIGA 30/07).
- (2) Have on hand the MSDS.
- (3) Good housekeeping is essential, e.g. keeping combustible material away from container storage or use areas.
- (4) Check for insects or foreign material before removing the valve protection cap.
- (5) Arsine cylinder valve outlet caps must be installed except when being filled or in use.
- (6) Always secure (nested, palletized or chained) the containers whether during transportation, storage or use.
- (7) Never strike an arc (with welding electrode) on the container.
- (8) Never allow containers to contact electrical circuits.
- (9) Never expose containers to corrosive chemicals or vapours, e.g. bleach or seawater.
- (10) Container valves must be securely closed, outlet seals tightly installed, and valve protection caps in-place during all storage and handling operation.

9.2 Storage

9.2.1 Segregation

- (1) Full and used containers should be segregated; however, containers with residual gas should be treated as if they were full.
- (2) Group containers according to the gas hazard they pose.
- (3) Arsine shall be stored in well-ventilated areas, away from incompatible gases (oxidizers, pyrophoric gases, etc.), flammable liquids, open flames, sparks and sources of heat. Incompatible groups shall be separated by appropriate distances or with fire partition. If local jurisdiction does not specify the distance, at least 6 meter separation is recommended.

9.2.2 Storage condition

- (1) Practice First-In-First-Out (FIFO) cylinder management.
- (2) Containers should be stored under dry conditions.
- (3) Containers should be stored on level ground to minimize toppling.
- (4) Store containers in such a way as to prevent the temperature of the containers from exceeding the national guideline.
- (5) Quantity of arsine stored should not exceed the design of the facility and should comply with national regulations.
- (6) Cylinders when stored vertically shall be secured (nested, palletized or chained) to prevent accidental tip-over. Standard compressed gas cylinders are designed to be stored vertically. In these cases, precaution must be taken to ensure that they are secured from falling.
- (7) Other small cylinders such as lecture bottles are more conveniently stored horizontally. However, some local regulations may require vertical storage for toxic liquefied gases, especially when equipped with pressure relief devices.

- (8) An energy relief wall or blast roof should be incorporated into the room design if flammable gases are stored in large quantities indoors. This wall or roof is designed to allow dissipation of pressure arising from an explosion.

9.3 Handling

9.3.1 Essentials

- (1) Personnel handling arsine cylinders should receive appropriate training.
- (2) Use appropriate materials of construction compatible for handling arsine. This information can be obtained from the MSDS and this document.
- (3) Always wear proper personal protective equipment when handling gas containers. Steel-capped safety shoes, safety glasses with side shields and leather gloves are recommended.
- (4) All piping, cabinet and equipment used to handle arsine should have electrical continuity sources and should be earthed.

9.3.2 Precautions

- (1) Remove valve outlet cap or connections slowly and look for signs of leakage before removing completely.
- (2) Always stand at the side of the valve outlet cap or connection when removing the cap or breaking a connection.
- (3) Always open valves slowly and carefully.
- (4) Containers with residual gas should be treated as if they were full.
- (5) The filling and use of arsine shall be done in exhausted enclosures or rooms with the discharge treated properly to below acceptable levels before emission into the atmosphere.

9.3.3 Checking

9.3.3.1 Container

- (1) Check cleanliness of the valve outlet and pigtails.
- (2) Leak check containers and connection before use.
- (3) Prior to entry, enclosed spaces containing highly toxic gas, including shipping containers, should be checked for leaks of the toxic gas in the absence of a maintained stationary detection system.

9.3.3.2 Piping

- (1) Always purge piping systems with inert gas before introduction of arsine.
- (2) Always purge piping systems with inert gas before disconnection of arsine cylinders.

9.3.4 Prohibition and restriction

- (1) Users shall not use adaptors to connect containers.
- (2) Do not over-tighten valves. Follow manufacturer's recommendations.
- (3) Never drag or slide the containers.
- (4) Never lift the container by the valve protection cap.
- (5) Use proper cylinder trolleys or appropriate moving devices to minimize rolling of cylinders over long distances.
- (6) Never use cylinders as a roller to move equipment.
- (7) The use of portable electronic devices, e.g. mobile hand phones and walkie-talkies, is prohibited, unless the devices have been proven to be intrinsically safe.
- (8) Prohibit sources of ignition, e.g. cigarette smoking.
- (9) Electrical equipment in the vicinity of arsine should be intrinsically safe following zoning guidelines in national regulations. If national regulations are not available, consult IEC (International Electro-technical Commission) or NEC (National Electrical Code).
- (10) Non-sparking tools are recommended to be used when working around arsine, and are required by some jurisdictions.

9.4 Security

Appropriate security measures should be implemented to prevent access to arsine cylinders by unauthorized personnel. For more details refer to AIGA Doc. 003/07 *Security Guidelines* or EIGA 907/05 *Security Guidelines*. Arsine can be used as a weapon of mass destruction (WMD) in the possession of a terrorist.

A sale policy for arsine shall be in place. It shall be ensured by a thorough review prior to the purchase being approved and the delivery being made that the customer has a valid reason to purchase arsine and that the tracking records during shipment of arsine shall be issued and kept.

10. Gas Supply to Point-of-use

Gas supply systems shall be located in a well ventilated area. Gas cabinets or ventilated enclosure shall be used for arsine supply systems. Provision shall be made to deal with emergencies, such as leaks in the supply system.

10.1 Process line control

A purge gas shall be used to purge the arsine system during commissioning of the system or prior to the maintenance. The purge gas is also used to purge the pigtail prior to and after cylinder change. Appropriate precautions shall be taken to ensure that the purge gas supply does not become contaminated with arsine. A dedicated purge gas source shared with other compatible gases a compressed gas cylinder shall be used. This will avoid the risk of back-feeding via the purge gas system into another incompatible process gas supply system.

Adequate precautions should be taken to ensure that arsine does not inadvertently come into contact with any oxidizing gas or a source of ignition.

10.2 Regulators

Regulators are used in arsine delivery systems to reduce and control the pressure from a high pressure source to a safe working pressure for use. All internal regulator parts should be compatible with arsine under normal operating conditions.

A regulator for semiconductor applications is functionally the same, but has different features than those of a regulator designed for general duty use. Regulators designed for controlling arsine in semiconductor processes are constructed of typically 316 or 316L stainless steel (SS), at times electro-polished. Regulators with stainless steel diaphragms should be used to avoid the potential of arsine diffusion through porous elastomer diaphragms and the potential diffusion of contaminants that are adsorbed on elastomeric diaphragms. Once a regulator has been used in arsine service, it should not be used for other gas service.

11. Gas Abatement Systems

Since arsine is a highly toxic material, a gas abatement system must be used to control any emission whether anticipated or not.

The best method of abatement depends on whether the arsine is being handled as a pure product, diluted in a mixture, or mixed with other by-products. Full product recovery tends to be practiced at manufacturing facilities. After use in a process, contamination and other issues utilizing chemical abatement may offer better solutions. Such an abatement system could be capable of dealing with other contaminants in the system. Disposal of arsine by any means must be done in an environmentally acceptable manner in compliance with all applicable regulations.

A competent person knowledgeable in the handling and processing arsine should design the equipment.

11.1 Basic principles of abatement

The following are the typical chemical reactions and physical adsorptions.

- (1) Reclamation or recovery
Cryogenic recovery
- (2) Oxidation via incineration
 $2 \text{AsH}_3 + 3 \text{O}_2 \rightarrow \text{As}_2\text{O}_3 + 3 \text{H}_2\text{O}$ and/or
 $2 \text{AsH}_3 + 4 \text{O}_2 \rightarrow \text{As}_2\text{O}_5 + 3 \text{H}_2\text{O}$
- (3) Oxidation via wet scrubber
 $\text{AsH}_3 + \text{Oxidant} + 4 \text{H}_2\text{O} \rightarrow \text{AsO}_4^{3-} + 11\text{H}^+ + 8 \text{e}^-$
- (4) Absorption/adsorption and reaction on a treated solid (with metallic oxides)
 $3 \text{CuSO}_4 + 2 \text{AsH}_3 \rightarrow \text{Cu}_3\text{As}_2 + 3 \text{H}_2\text{SO}_4$ or
 $6 \text{FeCl}_3 + \text{AsH}_3 + 3 \text{H}_2\text{O} \rightarrow 6 \text{FeCl}_2 + \text{H}_3\text{AsO}_3 + 6 \text{HCl}$
- (5) Physical adsorption on solid media
 $\text{AsH}_3 + \text{C} \rightarrow \text{C}[\text{AsH}_3]$ (C : Activated Carbon)

11.1.1 Reclamation or recovery

Reclamation of arsine is not a disposal method, as usually understood. This technique is for reclaiming residual gas and returning the arsine safely to suitable containers. Once reclaimed, arsine has to be re-processed, purified and analyzed before being reused.

All types of reclamation are strongly recommended both in the interests of the environment and the conservation of materials and energy.

The supplier of the material who will have the necessary product handling and container filling expertise is best suited for reclamation of gaseous arsine. Arsine should not be reclaimed to a container and returned without the written authority of the owner of the container.

Some users collect the arsine into the cylinders for treatment off-site.

11.1.2 Oxidation via incineration

While burning the arsine molecule can be done satisfactorily, capturing the toxic solid by-product requires extensive equipment. Proper clean-up procedures and employee protection from the arsenic oxide dust is critical.

For complete reaction, arsine shall be introduced directly into the burning flame.

11.1.3 Oxidation via wet scrubber

The typical wet scrubber used for arsine is a counter current packed tower.

Suitable arrangements should be made to ensure the system is monitored and shut down in the event of waste gas breakthrough. Factors to be taken into account when utilizing a wet scrubber:

- (1) Arsine input flow rate
- (2) pH control of the absorbent liquor

- (3) Temperature of the absorbent liquor
- (4) Provisions should be made to monitor both the inlet and outlet stream for arsine concentration.
- (5) Proper flow control should be installed in the waste arsine stream to enable the gas flow to be matched to the capacity of the scrubber.
- (6) Proper pressure control should be installed in the waste arsine stream to enable the gas flow to be matched to the operating capacity of the scrubber.
- (7) Use of inert purge as necessary to facilitate process line clean-up.
- (8) Consideration of discharge point from the scrubber exhaust, well away from air intake systems, downdrafts and personnel areas.

To prevent the risk of absorbent liquor sucking back into the system, proper controls should be in place. Consideration should be given to the use of non-sparking equipment as arsine is flammable. To ensure safe and efficient performance, proper monitoring of process conditions as well as the scrubber gas discharge effectiveness should be carefully considered.

Oxidizing solutions may consist of liquid solutions of potassium permanganate or sodium hypochlorite and work well for low concentrations of arsine.

11.1.4 Absorption/adsorption and reaction on a treated solid (with metallic oxides)

Arsine is fed directly into a vessel containing a bed of solid adsorbent. There are many solid absorbents available which strongly and readily adsorb/absorb and react with arsine. Simplicity and portability of a small solid-state absorber may favour the choice of this method under certain emergency conditions.

In this document, the terms absorption and adsorption are used interchangeably.

Factors to be taken into account when utilizing the solid-state absorber include:

- (1) Required arsine disposal rate
- (2) Quantity of arsine to be disposed
- (3) Acceptable frequency of changing the absorbent bed or system
- (4) Concentration of the arsine stream delivered into the absorber bed
- (5) Temperature rise effects from reaction between the arsine and the absorbent
- (6) Distribution system within the absorber bed to prevent channelling and premature breakthrough of un-reacted arsine
- (7) Absorbent particle size:
Generally small particles give a high contact area, which corresponds to greater efficiency. However, small particle sizes can lead to pluggage or high pressure drops and a tendency of channelling and premature breakthrough of un-reacted arsine
- (8) Provisions should be made to monitor both the inlet and outlet stream for arsine concentration.
- (9) Proper flow control should be installed in the waste arsine stream to enable the gas flow to be matched to the capacity of the absorber bed.
- (10) Proper pressure control should be installed in the waste arsine stream to enable the gas flow to be matched to the operating capacity of the absorber bed.
- (11) Use of inert purge as necessary to facilitate process line clean-up
- (12) Consideration of discharge point from the absorber bed exhaust, well away from air intake systems and personnel areas.

11.1.5 Physical adsorption on solid media

Arsine is fed directly into a vessel containing a bed of solid media. There are many types of solid media available which adsorb arsine. Adsorption capacity varies with solid type, for example using granular activated carbon, arsine capacities approach to 18% (by weight) of the total carbon weight. Off-gassing of arsine from solid media can occur so it is important to have proper controls and arsine monitoring in place. Heat is generated during arsine adsorption as a function of adsorption rate and arsine concentration. Temperature profiles through the bed containing solid media that are flammable must be monitored to prevent the solid media from igniting.

Simplicity and portability of a small solid-state absorber may favour the choice of this method under certain emergency conditions. Factors to be taken into account when adsorption on carbon are similar as those identified in "11.1.4 Absorption/adsorption on a treated solid", listed above.

11.2 User requirements

All personnel involved with the handling of arsine must be trained in the proper procedures for abatement control utilized at the site. A thorough knowledge of the product and its associated hazards is required. This would include, but not limited to:

- (1) Physical properties of arsine
- (2) Physical properties of abatement material
- (3) Toxicological properties of arsine
- (4) Characteristics of arsine
- (5) Operating documents

11.3 Waste stream disposal

Dispose in accordance with all applicable regulations. Waste streams may contain arsenic and be considered a toxic, hazardous waste. Proper management and control of waste is required. Refer to local and government regulations as they apply to waste management.

11.4 Waste Management

Nearly every operational process leaves behind some residual waste. Accelerating pressure on conserving natural resources, the impact of new technologies on resource use, increasing waste generation, and the need for more sustainable approaches to using natural resources represent new challenges to our society.

Local and government authorities tend to regulate all this waste under various programs. Only those companies licensed by the government are allowed to process these waste. Evaluating, selection and monitoring of the waste disposal company is a very important program that the hazardous waste generator must comply with. Full documentation of hazardous waste generation, shipments and final processing is critical to assure proper compliance and control.

The goals of proper waste management are to:

- (1) Protect society from the hazards of waste disposal
- (2) Conserve energy and natural resources by recycling and recovery
- (3) Reduce or eliminate waste
- (4) Clean up waste, which may have spilled, leaked, or been improperly disposed.

Users must promote and encourage the use of combined methods to manage solid waste. These methods are:

- (1) **Source reduction or waste prevention**, which means any practice that reduces the amount or toxicity of waste generated;
- (2) **Recycling**, which conserves disposal capacity and preserves natural resources by preventing potentially useful materials from being thrown away;
- (3) **Land filling**, landfills are well-engineered facilities that are located, designed, operated, and monitored to ensure compliance with regulations. Solid waste landfills must be designed to protect the environment from contaminants which may be present in the solid waste stream;
- (4) **Waste combustion**, can reduce the quantity of waste considerably. However, concerns of what types/quantities of toxics exit the scrubbers can become a local debate.

12. Emergency Response

12.1 Preparation

The purpose of preparation is to establish a system and assign responsibility in the event of an accident or other emergency situation.

The arsine user shall have procedures in place to address emergency situations that affect public health and environmental concern in the event of an accident. The **Emergency Plan** is such a document and identifies potential emergencies which are reasonably foreseeable, and specifies actions to prevent, prepare for, respond to, and recover from these. The **Emergency Plan** includes methods used to prevent and mitigate environmental impacts which could be associated with emergency situations.

The **Emergency Plan** shall be reviewed and updated periodically as applicable. Updated copies are provided to the local emergency planning committees and government officials as applicable. Training is provided for all personnel who may be involved with emergency response.

The **Emergency Plan** is tested periodically to ensure its effectiveness, including tests of related leak detection equipment, personnel protective equipment, protective systems and emergency communications. The **Emergency Contact List** is reviewed and updated with each change as applicable. Latest versions shall be maintained.

Arsine incidents vary considerably and **Emergency Plan** must consider the chemicals and quantities involved, types of hazard, response efforts required, number of responders needed and effects produced. Incidents may require immediate control measures (emergency) or long term activities (remedial action) to restore acceptable conditions. The plan activities are divided into interacting elements:

- (1) Recognition
- (2) Evaluation
- (3) Control
- (4) Information
- (5) Safety

12.1.1 Recognition

Recognizing the type and degree of the hazard presented by arsine is usually one of the first steps in responding to an incident.

12.1.2 Evaluation

The responder will predict the behaviour and anticipated problems associated with the material. Anticipated problems that may extend beyond the company property will require support/involvement from local officials. Material Safety Data Sheets (MSDS) or other product information will be used to help evaluate the nature and affect to the environment and public health.

12.1.3 Control

Control refers to those methods which prevent or reduce the impact of an incident. Control is addressed by remedial action in the form of documented procedures (plans). It is the responsibility of each facility and its personnel to assure proper procedures are in place and followed.

12.1.4 Information

An integral component of response is information. Notification of internal employees, local emergency response officials, corporate compliance, corporate safety and government agencies is as per established procedures. All accidents are documented and reviewed by the **Safety Committee** and/or

Emergency Response Team, to determine the root cause and to implement the corrective actions of the accident, the effectiveness of the response, corrective action warranted and notification to prevent repeat occurrence. Reference documents may include:

- (1) Material Safety Data Sheets (MSDS)
- (2) Emergency Plan
- (3) Standard Operating Procedures
- (4) Process Hazard Analysis Reviews
- (5) Technical Gas Data Books

12.1.5 Safety

All hazardous material responses pose varying dangers (health and safety) to responders, the environment and the neighbourhood. Safety considerations are an input to every activity that is undertaken and are an outcome of each response taken. It is the responsibility of all employees to work in a safe manner and follow established safety rules and regulations.

12.2 Response

Before attempting any emergency situation always ensure that responding personnel are properly trained, adequate and appropriate Personal Protective Equipment (PPE) is worn. Only those employees trained in responding to an incident shall do so...and only to the level of their training. The company's **Emergency Plan** shall identify the procedures and policies that will be followed in an emergency response. [32][33][34]

Off-site response requires interaction with other company's **Emergency Plan**. It could occur during transportation or at the customer site. Whether on-site or off-site, detailed information on how to handle such issues can be found in AIGA document 004/04 *Handling Gas Container Emergencies* and EIGA 80/01/E *Handling Gas Container Emergencies*. Also refer to EIGA document 30/07/E *Disposal of Gases*.

References

- [1] AIGA document 018/05/E, Safe Handling of Electronic Specialty Gases
- [2] Handbook of Compressed Gases Fourth Edition, "Arsine", Compressed Gas Association, p.268-273
- [3] Current Intelligence Bulletin 32, Arsine Poisoning in the Workplace, The National Institute Occupational Safety and Health at web site http://www.cdc.gov/niosh/79142_32.html
- [4] ATSDR Arsine, Agency for Toxic Substances & Disease Registry, Department of Health and Human Services at web site <http://www.atsdr.cdc.gov/MHMI/mmg169.html>
- [5] Yaws C.L., Matheson Gas Data Book, Seventh Edition, Chapter 7 Arsine, 2001, p.38
- [6] NIOSH (2005) Pocket Guide to Chemical Hazards, Arsine, The National Institute for Occupational Safety and Health at web site <http://www.cdc.gov/Niosh/npg/npgd0040.html>.
- [7] Wald, P.H., Becker, C.E., Toxic gases used in the microelectronics industry, *Occup. Med.*, 1(1), 1986, 105-117
- [8] Ohtani H, Horiguch S, Urano Y, Iwasaki M, Tokuhashi K, Kondo S, Flammability limits of arsine and phosphine, *Combustion and Flame*, 76 (1989), 307-310
- [9] ICSC: 0222, Arsine (ICSC), International Chemical Safety Cards, The International Programme on Chemical Safety at web site <http://www.inchem.org/documents/icsc/icsc/eics0222.htm>
- [10] Air Products and Chemicals, Inc., Material Safety Data Sheet Version 1.13, Arsine, MSDS Number 300000000007
- [11] Gas Encyclopaedia, Air Liquide, Arsine, also available at web site <http://encyclopedia.airliquide.com/encyclopedia.asp?LanguageID=11&CountryID=19&Formula=&GasID=4&UNNumber=&btnMolecule.x=7&btnMolecule.y=15>
- [12] Himi, K., "3.1.1 On the Stability of Special Gasses (Arsine and Phosphine) in the Atmosphere", Reports from the Kanagawa Prefect. Environ. Cent., Japan, 29, 1988, 58-63
- [13] Barbier, J.P., Darrieus, M., Study on the stability of arsine performed by l'air Liquide, CGA Specialty Gases committee summer meeting, June 1987
- [14] Code of Federal Regulations, Title 29- Labor, Part 1910- Occupational Safety and Health Standards, 1910.1018 Inorganic arsenic, The Department of Labour at web site http://www.osha.gov/pls/oshaweb/owadisp.show_document?p_table=STANDARDS&p_id=10023
- [15] Integrated Risk Information System, Arsenic, inorganic (CASRN 7440-38-2), <http://www.epa.gov/iris/subst/0278.htm>
- [16] Code of Federal Regulations, Title 40- Protection of Environment, Part 141- National Primary Drinking Water Regulations, 141.62 (b) Maximum contaminant level for inorganic contaminants, Environmental Protection Agency at web site <http://www.cfsan.fda.gov/~lrd/40F141.html>
- [17] Emergency Response Guidebook 2004, Guide 199 Gases-Toxic-Flammable, 186-187
- [18] NFPA 1 Fire Prevention Code, National Fire Protection Association
- [19] NFPA 70-2002 National Electrical Code®, National Fire Protection Association
- [20] NFPA 55 Compressed and Liquefied Gasses in Portable Cylinders, National Fire Protection Association
- [21] NFPA1: Uniform Fire Code, 2003 Edition, National Fire Protection Association
- [22] Henderson, Y., Haggard, H.W., Noxious Gases, 2nd Edition, Reinhold, NY, 1943, 241-242
- [23] ACGIH, Documentation of threshold limit values for Arsine. Cincinnati (OH): American Conference of Governmental Industrial Hygienists; 2001
- [24] Current Intelligence Bulletin 32, Arsine Poisoning in the Workplace, The National Institute Occupational Safety and Health at web site http://www.cdc.gov/niosh/79142_32.html
- [25] Safety and Health Topics: Arsine, Occupational Safety & Health Administration, Department of Labour at web site http://www.osha.gov/dts/chemicalsampling/data/CH_219590.html.
- [26] Concise International Chemical Assessment Document 47, Arsine: Human Health Aspects, World Health Organization, Geneva, 2002, ISBN 92 4 153047 2
- [27] ISO 10298: 1995(E), Determination of toxicity of a gas or gas mixture
- [28] IRDC (International Research & Development Corporation). Three acute inhalation toxicity studies of arsine on rats (final report). Report No. 533-001, 533-002, and 533-003. Mattawan (MI): IRDC; 1985
- [29] 2007 TLVs and BEIs, The American Conference of Governmental Industrial Hygienists, ISBN: 978-1-882417-69-8
- [30] Arsine Results, Acute Exposure Guideline Levels, Environmental Protection Agency at web site <http://www.epa.gov/oppt/aegl/pubs/results2.htm>

- [31] Technical Information, Gas Compatibility, Advanced Specialty Gas Equipment at web site
<http://www.asge-online.com/pdf/GasCompatibilityTable.pdf>
- [32] AIGA document 004/04/E, Handling Gas Container Emergencies
- [33] EIGA document 80/01/E, Handling Gas Container Emergencies
- [34] EIGA document 30/04/E, Disposal of Gases

Conversion Factors

Pressure

To Convert From	To	Multiply by	
atmosphere, standard (atm)	pascal (Pa)	101325	E 0
bar (bar)	pascal (Pa)	1	E 5
pound per square inch (psi)	pascal (Pa)	6.89476	E 3

Weight

To Convert From	To	Multiply by	
pound (lb)	kilogram (kg)	4.5359237	E -1

Length

To Convert From	To	Multiply by	
inch (in)	meter (m)	2.54	E -2
foot (ft)	meter (m)	3.048	E -1

Area

To Convert From	To	Multiply by	
square inch (in ²)	square meter (m ²)	6.4516	E -4
square foot (ft ²)	square meter (m ²)	9.290304	E -2

Volume

To Convert From	To	Multiply by	
cubic inch (in ³)	cubic meter (m ³)	1.6387	E -5
cubic foot (ft ³)	cubic meter (m ³)	2.8316	E -2
liter (L)	cubic meter (m ³)	1	E -3

Density

To Convert From	To	Multiply by	
pound per cubic inch (lb/in ³)	kilogram per cubic meter (kg/m ³)	2.76799	E 4
pound per cubic foot (lb/ft ³)	kilogram per cubic meter (kg/m ³)	1.60185	E 1

Temperature

To Convert From	To	Multiply by	
degree Fahrenheit (°F)	degree Celsius (°C)	$^{\circ}\text{C} = (^{\circ}\text{F} - 32) \times \frac{5}{9}$	